

<u>Part Number</u>	<u>Description</u>	<u>Price</u>	<u>Part Number</u>	<u>Description</u>	<u>Price</u>
<u>164 Electric Log Loader</u>			<u>164 Electric Log Loader (Cont'd)</u>		
164-53	Base	3.25	430-300	12 Volt Clear Lamp	.15
88-2	Binding Post Nut	.03	164-60	Roof	2.00
61-9	Hex Head Nut	.02	164-50	Connector Wire Assembly	.25
RCS-29	Contact Assembly Bottom	.15	4/36X1/4"	REC. RHI Screw	.02
RCS-21	Control Spring Assy. Center	.15	3651-13	Cam	.05
97C-4	Knob	.15	164-9	Platform Support Assembly	1.25
164-31	Chain	.20	3652-30	Coil	.40
164-30	Chain & Hook Assembly	.50	164-96	Connecting Link Formed	.10
97M-10	Drive Gear	.15	3652-22	Strap	.05
164-32	Lumber Hooks	.02	164-17	Platform & Stud Assembly	.40
164-33	Top Shaft	.10	164-73	Spacer	.05
164-35	Bottom Shaft	.10	5/40X1/8"	Cup Point Set Screw	.02
164-36	Sprocket	.25	164-37	Sprocket Spacer	.05
1681E-19	Armature Bushing	.10	6/32X11/16"	RH Groove Screw	.02
97M-6	Armature Assembly	1.00	#4X1/2"	S.T.R.H.I. #2" Screw	.02
1661E-29	Brushes Pr.	.35	4/36X3/4"	RHI Screw	.02
224E-101	Brush Springs Pr.	.10	4/36X1/2"	RHI Screw	.02
97M-12	Brush Plate Assembly	.40	6/32X7/8"	Rec. RHI Screw	.02
97M-1	Motor Complete	3.00	56-15	Lockwasher	.02
97M-7	Armature Shaft Worm	.15	97-72	Rubber Washer	.05
97M-9	Drive Worm and Shaft	.25	97C-1	Controller Complete	1.75
164-13	Coil Bracket Assembly	.75	4/40X3/8"	RH Groove Screw	.02
3651-22	Connecting Link	.05	160-1	Unloading Bin	.75
164-12	Lumber Post	.10			
3651-14	Plunger Assembly	.25			
164-11	Shaft Assembly Complete	.25			
164-16	Spring	.05			
164-64	Lumber (set)	.35			
156-10	Finial	.10			